




# Disassembly Instructions


for Inxpect Control Units

**WARNING:** Only technically competent personnel should disassemble Inxpect Control Units. Ensure the product is completely de-energized before disassembly begins

**DISCLAIMER:** This guide is intended for Control Units disposal purposes only. Disassembly voids the warranty. Inxpect SpA assumes no liability for post-disassembly malfunctions.



Type A



Type B


In need of assistance?  
Contact us at:  
[materials-compliance@inxpect.com](mailto:materials-compliance@inxpect.com)




# Disassembly Instructions

## for Inxpect Control Units type A & type B


1




2




3




4




5



6



i



SL 3x75

### Material list

N.	Material	Category
1	Polycarbonate	Plastic
2	Mix/Electronics	Mix/Electronics
3	Polyamide/Metal	Mix